# **Microplastics Losses in Runoff Following Biosolids Application**







## Background

## **Microplastics**











Primary sources

Secondary sources



60% MPs removed in primary clarifier

36% MPs removed in secondary treatment

Not biodegraded but retained in sludge Only 4% MPs in effluent



Objective: understand the fate of microplastics in soil and runoff after biosolids application.



## **Experiment Setup**

Simulate rainfall events on plots with biosolids application



Eight 1m x 1m plots:

Two control plots without biosolids application

Three spreading plots: spread biosolids on the soil surface Three incorporating plots: incorporate biosolids into the soil Application rate:


720 g biosolids (class B, 30% water content, 110 MPs/dry g)

### Simulated rains:

1st 2nd 3rd simulation: 0.6 inch/ 10 min

4th 5th simulation: 0.6 inch/5 min

### Zhengxi Li; Belinda Sturm, PhD Civil, Environmental, Architectural Engineering Department, University of Kansas



### Conclusion

#### In runoff:

- · More runoff volumes and more TSS losses from spreading plots
- · At low rainfall intensity, incorporation of biosolids into soil increased MPs losses compared to spreading application method;
- · At high rainfall intensity, runoff volume increased and MPs losses from spreading plots increased:
- Explanation:

Incorporation created much more contact surface and provided the opportunity for runoff to flush the microplastics retained in the relative deeper layer. During the 4th simulation, rain at high intensity ruined the flat surface layer of spreading plots thus losing more microplastics, and the surface continued to be ruined during the 5th simulations thus releasing even more.

### In soil:

- · The huge impact of biosolids application on MPs concentration in soil was confirmed: 117% (spreading plots) and 97% (incorporating plots) net increases
- Infiltration was confirmed by the increase of MPs concentration at 5-10 cm soil depth
- · Incorporating of plots accelerated infiltration

#### **Future Directions:**

- Relationship between TSS losses and MP losses
- · Estimate of MPs weight and report concentration in mg MPs/ g soil or L runoff

## **Extraction and Quantification**

Filtration peroxidation

Density Separation Nile Red Staining Microscope



Runoff samples:

Measurements:

· Runoff volume

• MPs

• TSS

0-5 cm

**Sampling Methods** 

· Collected one day after each simulation by coring tool from

· Collected during each simulation by ISCO auto samplers

5-10 cm

Soil depth

10- 15cm

• 0-5 cm, 5-10 cm, and 10-15 cm soil depth Measurements:

• MPs











KIL is an FO/AA institution

